



MOUNTING SUGGESTIONS:

Harley-Davidson®
FL Touring 1993-2016
Saddlebag & Tour-Pak® Lid Covers

Installation of Mustang lid cover:

1. For easiest install, allow the lid cover to warm so the vinyl is more pliable. Put it in its bag, and place it in a warm location (such as on a dashboard on a sunny day) for about 10-20 minutes. **Do not overheat the cover as the vinyl may melt.**



2. Position the front edge of the lid cover onto the front of the lid.
3. Stretch the two back corners onto the lid, one at a time. The fit will be extremely tight.
4. Adjust the cover on the lid for best fit.
5. The lid may be difficult to close and latch the first time. Once the vinyl has been compressed under the lid, the lid will operate normally.

Enjoy the custom look of your new Mustang lid covers!



These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392 or 413-668-1100, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Refers to part numbers: 77600, 77601, 77602, 77603, 77604, 77605, 77623, 77624, 77625, 77626, 77627, 77628

You are cordially invited to
— Tour the Mustang Factory —

See how our craftspeople take pride in transforming raw materials into the world's highest quality, most comfortable handcrafted seats. Please contact Mustang for more information regarding tours of our historic Three Rivers, Massachusetts, facility (only 75 miles west of Boston; 150 miles northeast of New York City). Our two hour tours are by reservation only; we can accommodate groups from 2 to 24. We promise you will ride away with an entirely new awareness of what you put between you and your bike.