



MOUNTING SUGGESTIONS:

Harley-Davidson®
FXR 1982-1994, 1999-2000
Perewitz Signature Solo

| | | |
|-----------------------------|---|--|
| Hardware (Included): | 76990 (Hinge mounted) 5/16" -24 x 1/2" hex bolt x 4 | 76991 (Frame mounted) White nylon washer x 2 Chrome washer x 2 5/16" -24 x 3/4" Allen bolt x 2 Front mounting bracket |
| Tools needed: | SAE hex wrenches | SAE Allen and hex wrenches |

Removal of Stock Seat:

One-piece:

Remove rear fender screw and set aside. Slide seat back and up to remove.



Two-piece:

1. Unlatch solo and pivot up to expose hinge.
2. Disengage plastic retaining clip on hinge, slide solo back to clear the hinge and remove.
3. Remove rear fender screw and set aside. Loosen two front mounting bolts, and slide passenger seat back and up to remove.

Installation of Perewitz Signature Solo:

76990 (Hinge mounted)

1. Transfer the hinge bracket from the stock seat to the Mustang solo with the supplied bolts using a $\frac{1}{2}$ " hex wrench. Be sure it is mounted securely.
2. Reconnect the hinge to the frame. Pivot the seat down onto the frame.

76991 (Frame mounted)

1. Using a $\frac{1}{2}$ " hex wrench, remove the two bolts and washers at the rear base of the fuel tank.
2. Install supplied front mounting bracket to the tank with the stock bolts. Do not use the washers.



3. Engage the seat's front bracket into the mounting bracket.
4. Position the two white nylon washers between the seat's rear mounting brackets and the fender nuts.
5. Place a chrome washer over each bracket, and secure with the supplied Allen bolts using a $\frac{3}{16}$ " Allen wrench.

Using the pocket:

Note: Neither Mustang Motorcycle Products, LLC, or Jody Perewitz or Perewitz Cycle Fab make any representation or warranty, either express or implied, in association with the use or placement of any article in the seat pocket nor as to the possible breakage, loss or damage due to crushing, cracking or dropping of any article placed partially or fully inside the seat pocket. Place items inside the seat pocket at your own risk.

1. Pull the ribbon out of the pocket and hold it along the center line of the seat.
2. Place the object you are storing into the pocket, and allow it to push the ribbon into the pocket.
3. To remove the object from the pocket, pull the ribbon gently, and use your other hand to prevent the object from falling.

Enjoy the comfort and custom look of your new Mustang seat!



These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392 or 413-668-1100, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Refers to part number: 76990, 76991

You are cordially invited to
— Tour the Mustang Factory —

See how our craftspeople take pride in transforming raw materials into the world's highest quality, most comfortable handcrafted seats. Please contact Mustang for more information regarding tours of our historic Three Rivers, Massachusetts, facility (only 75 miles west of Boston; 150 miles northeast of New York City). Our two hour tours are by reservation only; we can accommodate groups from 2 to 24. We promise you will ride away with an entirely new awareness of what you put between you and your bike.