



.....**Mounting Suggestions**
Harley-Davidson® FXR 1982-94 & 1999-00
.....**Two-Piece Seat**

Tools Required:

- SAE Sockets
- SAE Open-End Wrenches
- Small Screwdriver

Hardware:

- OEM Hinge & Latch System (Stock)
- Fender Bolts & Washers (Stock)
- Fender Screw (Stock)
- Mustang Seat Bolts Part#78027 (Optional- Sold Separately)



Baseplate Features:

Mustang two-piece FXR seats are designed to fit all 1982-94 models with hinged front seats. The formed steel baseplates of the solo and the passenger seats have rubber bumpers to minimize vibration and to protect the paint. The rear baseplate is also carpeted to protect the fender.

Use the OEM hinge and latch on the new solo. Passenger seat has a chrome rear tab and front slots in the base to fit directly to the fender bolts.

Stock One-Piece Seat Removal Steps

1. Remove rear fender screw located at back of seat and set aside. The rear fender screw will be used to attach the passenger seat of your new Mustang Two-Piece Seat.
2. Slide one-piece seat back and up to remove.

Stock Two-Piece Seat Removal Steps

1. Unlatch solo seat to expose the hinge.
2. Push plastic retaining clip of hinge with small screwdriver or fingers.
3. Slide solo seat back to clear hinge and remove.
4. Unbolt the OEM hinge and latch from the bottom of the solo seat and set aside. The OEM hinge and latch will be used on

Stock Passenger Seat Removal Steps

1. Remove rear fender screw located at back of seat and set aside. The rear fender screw will be used to attach the passenger seat of your new Mustang Two-Piece Seat.
2. Loosen front mounting bolts.
3. Slide passenger seat back and up to remove.

Mounting Suggestions: Harley-Davidson® FXR 1982-94 & 1999-00 Two-Piece Seat continued from page 1)

Mounting of Mustang Solo Seat

1. Remove OEM hinge and latch system and mount to the Mustang seat. (Fig. I)
2. Latch seat to the frame.

Fig. I



Mounting of Mustang Passenger Seat

1. Install stock fender bolts and washers into the fender.
2. Engage front slots in baseplate under washers onto stock fender bolts.
3. Secure stock fender bolts.
4. Align rear tab with stock fender screw.
5. Secure rear tab with stock fender screw

Optional Mustang Mounting Bolts (sold separately)

1. Install Mustang Seat Bolts (Part #78027-5/16"-24 thread) into fender locations. (Fig. II)
2. Engage front slots in baseplate into slots on bolts.
3. Align rear tab with threaded hole in fender.
4. Secure rear tab with stock fender screw

Fig. II



Enjoy the Comfort of your new Mustang Seat!



These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392, Monday through Friday 9:00 - 5:30 Eastern, or send an email to questions@mustangseats.com, or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Refers to part numbers: 75321, 75515, 75518, 75083, 75520, 75521, 75737, 75760, 75765, 75523, 75528, 75529