



Mounting Suggestions for the Kawasaki Vulcan 1500 Classic 1996-2008 and Nomad 1999-2004 Two-Piece Seat

Tools Required:

- Metric Wrenches
- Metric Sockets

Hardware:

- Stock 6 mm seat bolts
- One Nylon Washer (Included)
- One Rear Fender Bracket- For Nomad & Fuel Injected (FI) Models Only (Included)

Baseplate Features:

The two-piece, marine-grade fiberglass baseplate is a direct replacement for the stock two-piece seat. Rubber bumpers are positioned to protect the frame and fender. Nose and side bracket locations are slightly different on Nomad and Fuel Injected (FI) Vulcans than on Carburetor equipped Vulcans.

Stock Seat Removal Steps

1. Remove the stock side bolt on each side of the solo.
2. Slide nose of solo forward and up to remove.
3. Remove at front of passenger seat.
4. Slide passenger seat forward to release from fender brackets.
5. On the Nomad and FI Models: Remove the slotted seat bracket from fender.

Nomad Pictured



Mounting of Mustang Seat

1. Nomad and FI Models only: Install supplied fender bracket in rear set of holes using stock bolts.
2. Slide passenger seat back to engage into bracket.
3. Use stock bolt and nylon washer to secure front of passenger seat.
4. Place rear of solo onto frame.
5. Push solo back against the passenger seat, compressing the foam until the nose bracket of solo slides under the large tank washer. Secure solo with stock side bolts.

Nomad Pictured



Enjoy the comfort of your new Mustang Seat!



These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392, Monday through Friday 9:00 - 5:30 Eastern, or send an email to questions@mustangseats.com, or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Ref part #75966, 75790, 75980, 75785, 79211, 79235, 75960, 75780, 79210, 79233