



MOUNTING SUGGESTIONS:

Harley-Davidson® FLT/FLHT 1991-1996 One-piece Seat

Hardware:	Stock 1/4" -20 x 1/2" rear fender screw "Z" bracket with 2 10-32 screws (included)
Tools needed:	Phillips screwdriver

Installation of Mustang Seat:

1. Install the supplied chrome triangle "Z" bracket onto seat baseplate and tighten screws securely.



2. Engage tab on frame of bike into receiver at nose of seat.
3. Firmly push seat forward so the nose meets the chrome dash panel.
4. Align slot in "Z" bracket with threaded hole in Tourpak platform.
5. Secure seat with stock screw.

Note: If installing without the Tourpak, you will need a flat bracket.
Contact Mustang to get this bracket.

Enjoy the comfort and custom look of your new Mustang seat!



These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392 or 413-668-1100, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Refers to part numbers: 75525, 75555, 75565

**You are cordially invited to
— Tour the Mustang Factory —**

See how our craftspeople take pride in transforming raw materials into the world's highest quality, most comfortable handcrafted seats. Please contact Mustang for more information regarding tours of our historic Three Rivers, Massachusetts, facility (only 75 miles west of Boston; 150 miles northeast of New York City). Our two hour tours are by reservation only; we can accommodate groups from 2 to 24. We promise you will ride away with an entirely new awareness of what you put between you and your bike.