



MOUNTING SUGGESTIONS:

Kawasaki Vulcan 1600 Classic/Nomad Tank Bib

Installation of Mustang tank bib:

1. Remove the seat, then remove the two mounting bolts at the base of the tank with a 12mm wrench, then remove the three dash Allen bolts with a 4mm Allen wrench.
2. Lift the chrome cover off the tank, then lift the speedometer bracket just enough to slide the tank bib underneath. Align the square hole over the mounting boss, then push the speedometer bracket back into place.
3. Re-install the three dash bolts and tighten securely with a 4mm Allen wrench.
4. Push the two tank bolts through the holes in the base of the bib and re-install into the tank and frame. Tighten securely with a 12mm wrench.
5. Re-install the seat.



Enjoy the custom look of your new Mustang tank bib!



These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392 or 413-668-1100, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Refers to part numbers: 93183, 93184, 93314, 93315

**You are cordially invited to
— Tour the Mustang Factory —**

See how our craftspeople take pride in transforming raw materials into the world's highest quality, most comfortable handcrafted seats. Please contact Mustang for more information regarding tours of our historic Three Rivers, Massachusetts, facility (only 75 miles west of Boston; 150 miles northeast of New York City). Our two hour tours are by reservation only; we can accommodate groups from 2 to 24. We promise you will ride away with an entirely new awareness of what you put between you and your bike.