



MOUNTING SUGGESTIONS:

Triumph America & Speedmaster 2002-2008 - Tank Bib

Hardware:	Stock 5mm x 16mm Allen bolt x 3
Tools needed:	5mm Allen wrench

Installation:

1. Remove seat from motorcycle.
2. Remove the three 5mm x 16mm Allen bolts from the dash with a 5mm Allen wrench and set aside.
3. Position the three rectangular holes in the Mustang tank bib over the three dash mounts
4. Hook the elastic loop at the bottom of the bib over the tab at the back of the tank.
5. Re-install the three Allen bolts through the dash into the tank mounts, adjust the fit of the bib, and tighten the bolts securely.
6. Re-install seat.



These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392 or 413-668-1100, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Refers to part numbers: 93234, 93235, 93236, 93237

You are cordially invited to
— Tour the Mustang Factory —

See how our craftspeople take pride in transforming raw materials into the world's highest quality, most comfortable handcrafted seats. Please contact Mustang for more information regarding tours of our historic Three Rivers, Massachusetts, facility (only 75 miles west of Boston; 150 miles northeast of New York City). Our two hour tours are by reservation only; we can accommodate groups from 2 to 24. We promise you will ride away with an entirely new awareness of what you put between you and your bike.