

These decorative studs are chrome-plated brass, not steel, and will never rust; they are 12.5 mm (1/2") in diameter. Chrome studs have two prongs and a one-piece design; black pearl-centered studs have four prongs for added stability.

Installation:

1. Holding the stud in your fingers, bend the 1/4" prongs of the stud in slightly (not more than 5 degrees each) so they will line up better with the existing holes from the previous stud.

2. We suggest carefully placing a drop of Super Glue or other adhesive on the inside of each prong and on the bottom center of the stud for extra strength.

3. Line up the prongs of the stud with the holes in the vinyl, and gently insert the stud.

4. Bend the prongs in by pinching them through the vinyl with your finger into the back of the stud.

(If back of stud is not accessible, pinch the material up so you can feel the back of the stud. A very small screwdriver can be inserted into the hole to assist in bending the prongs if necessary. Please be careful not to bend the prongs so far as to puncture the material with the tip of the prong.)







These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392 or 413-668-1100, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Refers to part numbers: 78021, 78023, 78079, 78089

You are cordially invited to - Tour the Mustang Factory-

See how our craftspeople take pride in transforming raw materials into the world's highest quality, most comfortable handcrafted seats. Please contact Mustang for more information regarding tours of our historic Three Rivers, Massachusetts, facility (only 75 miles west of Boston; 150 miles northeast of New York City). Our two hour tours are by reservation only; we can accommodate groups from 2 to 24. We promise you will ride away with an entirely new awareness of what you put between you and your bike.