



## MOUNTING SUGGESTIONS:

### Yamaha V-Star 1100 Custom 1999-2011 One-piece Seat

<b>Hardware:</b>	Stock rear nut and chrome washer Small shoulder washer Black nylon washer with ½" hole
<b>Tools needed:</b>	Metric wrenches

#### Removal of stock seat:

1. Remove the rear fender screw or bolt.
2. Slide the passenger back to remove.
3. Remove the two screws holding the solo bracket to the fender.
4. Slide solo back and up to remove.
5. Re-install the two bracket screws into the fender.



#### Installation of Mustang seat:

1. Slide nose bracket on the front of the seat into the receiver at the base of the gas tank.
2. For models with a rear fender hole and mounting bolt, place the supplied shoulder washer between the fender mount and the seat bracket and secure with stock chrome washer and bolt. For models with a fender stud and a mounting nut, place the ½"-hole washer over the stud, lower the seat bracket over the stud, and secure with stock chrome washer and nut.

Enjoy the comfort and custom look of your new Mustang seat!



These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392 or 413-668-1100, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to [questions@mustangseats.com](mailto:questions@mustangseats.com) or visit our website at [www.mustangseats.com](http://www.mustangseats.com).

For care and maintenance of our seats, please go to our website under "Support".

Refers to part number: 76158

**You are cordially invited to**  
**— Tour the Mustang Factory —**

See how our craftspeople take pride in transforming raw materials into the world's highest quality, most comfortable handcrafted seats. Please contact Mustang for more information regarding tours of our historic Three Rivers, Massachusetts, facility (only 75 miles west of Boston; 150 miles northeast of New York City). Our two hour tours are by reservation only; we can accommodate groups from 2 to 24. We promise you will ride away with an entirely new awareness of what you put between you and your bike.