



Mounting Suggestions for the Harley-Davidson® FX/FL Big Twin 1965-1984 Two-Piece Seat

Tools Required:

- Phillips Screwdriver

Hardware:

- Stock Rear Fender Screw
- Two rubber expansion plugs with threaded inserts and bolts (Included for Solo Only installation)



Baseplate Features:

The 16 gauge formed steel baseplate is black powder coated. Rubber bumpers on the solo and carpet on the rear seat prevent them from touching the frame or fender.

Stock One-Piece Seat Removal Steps

1. Remove rear fender screw located behind the passenger seat and set aside. The stock rear fender screw will be used to attach your new Mustang Two-Piece Seat.
2. Slide seat back and up.

Mounting of Mustang Solo & Passenger Seat

1. Remove two screws from back of Mustang solo seat.
2. Align two chrome tabs located at the front of the passenger seat with the mounting holes in back of solo.
3. Screw rear seat and solo together.
4. Slide solo front forks under frame.
5. Align chrome rear tab located at back of passenger seat with stock hole in fender.
6. Secure in place with stock fender screw to complete the installation process. *Note: Use of side brackets optional and would use the rubber expansion plugs, threaded inserts, and bolts used for a solo only installation.*

Enjoy the Comfort of your new Mustang Seat!



These steps are guidelines to help you install your new Mustang product. If you need further assistance please call us at 800-243-1392, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at <http://www.mustangseats.com>