



Mounting Suggestions for Fender Bibs

Honda VTX 1300 Retro, 1800 Retro & 1800N

1. Remove seat.
2. Remove rear seat mounting bracket from fender.
3. Attach rear of fender bib with stock 6mm screw.
4. Front of bib attaches to fender using supplied Velcro[®] tape.
5. Install solo. (Velcro[®] piece remaining on fender is hidden under solo when bib is removed.)

NOTE: Mustang recommends removal of fender bib before reinstalling rear seat. Mounting a rear seat over a fender bib may result in damage to the bib, poor seat alignment or other problems.



Plain



Studded



If you have any questions, contact one of our seat experts at questions@MustangSeats.com or **800-243-1392** or 860-582-9633 Monday-Friday, 9:00 to 5:30, Eastern time. Enjoy the custom look of your Fender Bib.