

MOUNTING SUGGESTIONS:

Yamaha Raider 2008-2017

One-piece Seat

Tools needed: Metric socket wrenches and extension

Removal of stock seat:

- 1. Insert ignition key into the left side cover and turn counter-clockwise until a click is heard and solo seat is unlocked.
- 2. Lift the nose of the solo and remove the seat from the frame.
- 3. Locate the two 10mm bolts under the front of the passenger seat and remove with a 10mm socket wrench and extension.





- 4. Slide passenger seat forward and remove from fender.
- 5. Remove the center bracket from the rear fender. Replace the bolts into the fender after removing the bracket.

Installation of Mustang seat:

- 1. Align the rear tab of the Mustang seat with the rearward mounting bracket on the fender, and push seat back to engage.
- 2. With the key in the left side cover turned counter-clockwise, align the front bracket with the frame latch.
- 3. Push nose of seat down firmly until it clicks, signifying the seat is latched into position. Ensure this bracket is firmly engaged before riding.

Enjoy the comfort and custom look of your new Mustang seat!



These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392 or 413-668-1100, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Refers to part number: 76266

You are cordially invited to Tour the Mustang Factory

See how our craftspeople take pride in transforming raw materials into the world's highest quality, most comfortable handcrafted seats. Please contact Mustang for more information regarding tours of our historic Three Rivers, Massachusetts, facility (only 75 miles west of Boston; 150 miles northeast of New York City). Our two hour tours are by reservation only; we can accommodate groups from 2 to 24. We promise you will ride away with an entirely new awareness of what you put between you and your bike.